



For a full set of Programming Instructions refer to your MCC2/MCD2 User Manual

Setting Time and Day

- 1 Press **•C**
- 2 Press **∇** or **Δ** to set correct time
- 3 Press **✓** to confirm
- 4 Press **∇** or **Δ** to set correct day (1 = Monday, 2 = Tuesday...)
- 5 Press **✓** to confirm

Programming 4-Event Time and Temperature

- 1 Press and hold **✓** for 3 seconds

Days 1 2 3 4 5 (Monday Tuesday Wednesday Thursday Friday) **Factory Settings**

- | | | |
|----|--|-------|
| 2 | Press ∇ or Δ to change start time | 06:00 |
| 3 | Press ✓ to confirm | |
| 4 | Press ∇ or Δ to change set temperature | 25°C |
| 5 | Press ✓ to confirm | |
| 6 | Press ∇ or Δ to change start time | 08:00 |
| 7 | Press ✓ to confirm | |
| 8 | Press ∇ or Δ to change set temperature | 20°C |
| 9 | Press ✓ to confirm | |
| 10 | Press ∇ or Δ to change start time | 16:00 |
| 11 | Press ✓ to confirm | |
| 12 | Press ∇ or Δ to change set temperature | 27°C |
| 13 | Press ✓ to confirm | |
| 14 | Press ∇ or Δ to change start time | 23:00 |
| 15 | Press ✓ to confirm | |
| 16 | Press ∇ or Δ to change set temperature | 20°C |
| 17 | Press ✓ to confirm | |

Wake ☀
Higher Temperature
first thing in the Morning

Out 🏠➡
Lower Temperature
when at Work

Home 🏠←
Higher Temperature when
come Home from Work

Night ☾
Lower Temperature
Over Night

Days 6 7 (Saturday Sunday)

- | | | |
|----|--|-------|
| 18 | Press ∇ or Δ to change start time | 08:00 |
| 19 | Press ✓ to confirm | |
| 20 | Press ∇ or Δ to change set temperature | 27°C |
| 21 | Press ✓ to confirm | |
| 22 | Press ∇ or Δ to change start time | 23:00 |
| 23 | Press ✓ to confirm | |
| 24 | Press ∇ or Δ to change set temperature | 20°C |
| 25 | Press ✓ to confirm | |

Wake ☀
Higher Temperature
during the Day

Night ☾
Lower Temperature
Over Night

NOTES

- Set temperatures can be in the range from OFF, +5°C to +40°C
- This Thermostat features *Adaptive* technology that enables it to calculate when it needs to switch ON so that the required temperature is reached at the set time.
- To return the Thermostat to Factory Settings, Press **•R**. Time and Day is also reset and must be set according to "Setting Time and Day".
- Other weekly programs can be set: 4 events for 6 weekdays and 2 events on Sundays, 4 events for all 7 days of the week.

ENERSAVE Products Limited

NEW ZEALAND • PO Box 8867, CHRISTCHURCH • Free Phone/Fax : 0800 508 509 • Email : info@enersave.co.nz • www.enersave.co.nz
 AUSTRALIA • Unit 107/45 Gilby Road, Mount Waverley, VICTORIA 3149 • Phone 61 3 9558 8211 • Fax 61 3 9558 8222 • ARBN 093 247 413